

TOOLS LIST

Liquid Applied Membrane Waterproofing

- Notched Squeegees (5 minimum) 90 mil or correct size (with Frame and handle) for Base Coat
- Notched Trowels
- 2 Rolling Carts
- 90 mil Squeegees
- 3/4" Nap Roller Covers (24 minimum)
- Roller Frames - 3 with Extended Handles
- Heavy Duty Scissors**
- Measuring wheel
- Utility Knives
- Margin Trowel
- Solvent (xylene)
- Rags
- Plastic gloves
- Notched Trowels
- Caulking Guns (Sausage and Cartridge)
- Spiked Shoes
- Common and Phillips Screw Driver
- 5 gallon Paint Can Opener and/or 5 in 1 Tool
- 1/2" Drill (Minimum)
- Mixing Paddle
- 2 1/2 quart Measuring pails (2 minimum)
- Water Access and/hose and nozzle
- Chalk Line
- Masking Tape
- Trash Bags
- Hammer
- Paint Brushes
- Brooms
- Tin Snips
- (12-14)18" 3/8" rollers and covers
- DON'T FORGET THE COATINGS!**
- Enviro-Grip #5 primer
- B-Tuff 921
- Terra-Shield WC-100
- Polyester Fabric