



NOTES:

1. APPLY PRIMER TO METAL FLASHINGS AT 300 SQ/FT P/GAL AND ALLOW PRIMER TO DRY.
2. REMOVE & REPLACE ALL FAILED SEALANT AND INSTALL AS REQ'D.
3. SEAL JOINT FLUSH WITH PTS E-101 JOINT SEALANT.
4. APPLY SUPER SEAL TAPE OVER ALL JOINTS IN PLYWOOD.
5. APPLY P-TUFF CLASSIC SAND SLURRY AT 8.3 GALLONS P/100 SQ/FT.
6. BROADCAST AGGREGATE TO REFUSAL.
7. APPLY TOPSHIELD TOP COAT AT 80 SQ/FT P/GALLON.

\* P-TUFF™ BASE MATERIAL IS A MIXTURE OF 4 PART P-TUFF™ CLASSIC, SLV OR FLEX AND 1 PART OF WATER BY VOLUME  
 \* REPAIR CRACKS AND JOINTS 2.09-2.12 GENERAL GUIDELINES



Poly-Tuff Systems International

8550 West Desert In Road  
 Suite 102-451  
 Las Vegas, NV 89117  
 P 1-866-977-8833  
 F 1-800-804-0182  
 www.polytuffus.com  
 sales@polytuffus.com

DETAIL NAME & DESCRIPTION

**FLEXIDECK™ P-ML**  
 Heavy Duty Metal Lath Reinforced  
 Decking System for Wood Substrates

DESIGNED <b>B. CLANTON</b>	SHEET <b>1 OF 1</b>
DRAWN <b>N. BASTANI</b>	SCALE <b>N.T.S</b>
DATE <b>5/18/2017</b>	DETAIL NO. <b>P-ML</b>