



## TOOLS LIST

(PolyTuff Water Cured Coating and Top Coat)" ½" and 3/8" Nap Roller Covers (12 minimum) Use 3/8" nap for primer and ½" for backrolling and topcoat (application)

Roller Frames – (3-5) 9" with Extended Handles

Utility Knife

Margin Trowel

Solvent

Rags

Plastic gloves

Pool Trowel for sand slurry applications

Caulking Guns (Bulk and Cartridge)

10 empty 5 gallon pails

Masking Paper with 2" Tape

Common and Phillips Screw Driver

5 gallon Paint Can Opener and/or 5 in 1 Tool

High speed HD Drill (900 RPM Minimum)

Mixing Paddle

**DON'T FORGET YOUR COATING!**

2 ½ quart Measuring pails (2 minimum)

Water Access and/hose

Chalk Line

¾" and 3/8" masking and duck tape

Trash Bags

6 Weenie Rollers with frames

Hammer

Sand or Aggregate

Consult with your Tech Rep on appropriate mesh  
NO HOME DEPOT SAND

5-10 3" cheap paint brushes for detailing.

Brooms

Tin Snips and Needle Nose Pliers

Wood Stir Sticks

Small hand grinder

Trash Bags

40-60 Mil Squeegee blades with Handle and Frames .

Polyethylene Film