



NOTES:

1. REMOVE & REPLACE ALL FAILED SEALANT AND INSTALL AS REQ'D
2. SEAL JOINT FLUSH WITH PTS E-101 JOINT SEALANT
3. APPLY PRIMER AND ALLOW PRIMER TO DRY (PRIMER IS OPTIONAL ON PLYWOOD)
4. PRIME METAL FLASHINGS WITH ENVIRO-GRIP #2SC PRIMER AND ALLOW TO DRY
5. APPLY 30 MIL BASE COAT OVER ALL JOINTS AND CRACKS AND INREFORCE WITH 3" STRAIGHT JACKET TAPE
6. APPLY 60 MILS OF P-TUFF CLASSIC BASE COAT AT 25 SQ/FT P/GALLON
7. APPLY SECOND COAT AT 80 SQ/FT P/GALLON AND BROADCAST AGGREGATE TO REFUSAL
8. APPLY TOPSHIELD EST-FR AT 80 SQ/FT P/GALLON
9. APPLY TOPSHIELD EST AT 125 SQ/FT P/GALLON
10. APPLY COMPLETE FLEXIDECK SYSTEM AS SPECIFIED

* P-TUFF™ BASE MATERIAL IS A MIXTURE OF 4 PART P-TUFF™ CLASSIC, SLV OR FLEX AND 1 PART OF WATER BY VOLUME

* THE ICC-ES # AND FIRE RATING

* REPAIR CRACKS AND JOINTS 2.09-2.12 GENERAL GUIDELINES



Poly-Tuff Systems International

8550 West Desert In Road
Suite 102-451
Las Vegas, NV 89117
P 1-866-977-8833
F 1-800-804-0182
www.polytuffus.com
sales@polytuffus.com

DETAIL NAME & DESCRIPTION

FLEXIDECK™ P-B
ICC-ES #ESR-2785
Class B Fire Rated System
for Concrete

DESIGNED

B. CLANTON

DRAWN

N. BASTANI

DATE

5/18/2017

SHEET

1 OF 1

SCALE

N.T.S

DETAIL NO.

P-B