



NOTES:

1. REMOVE & REPLACE ALL FAILED SEALANT AND INSTALL AS REQ'D
2. SEAL JOINT FLUSH WITH PTS E-101 JOINT SEALANT
3. APPLY PRIMER AND ALLOW PRIMER TO DRY (PRIMER IS OPTIONAL ON PLYWOOD)
4. PRIME METAL FLASHINGS WITH ENVIRO-GRIP #2SC PRIMER AND ALLOW TO DRY
5. APPLY 30 MIL BASE COAT OVER ALL JOINTS AND CRACKS AND INREFORCE WITH 3" STRAIGHT JACKET TAPE
6. APPLY 60 MILS OF P-TUFF CLASSIC BASE COAT AT 25 SQ/FT P/GALLON
7. APPLY SECOND COAT AT 80 SQ/FT P/GALLON AND BROADCAST AGGREGATE TO REFUSAL
8. APPLY TOPSHIELD EST-FR AT 80 SQ/FT P/GALLON
9. APPLY TOPSHIELD EST AT 125 SQ/FT P/GALLON
10. APPLY COMPLETE FLEXIDECK SYSTEM AS SPECIFIED

\* P-TUFF™ BASE MATERIAL IS A MIXTURE OF 4 PART P-TUFF™ CLASSIC, SLV OR FLEX AND 1 PART OF WATER BY VOLUME

\* THE ICC-ES # AND FIRE RATING

\* REPAIR CRACKS AND JOINTS 2.09-2.12 GENERAL GUIDELINES



Poly-Tuff Systems International

8550 West Desert In Road  
Suite 102-451  
Las Vegas, NV 89117  
P 1-866-977-8833  
F 1-800-804-0182  
www.polytuffus.com  
sales@polytuffus.com

DETAIL NAME & DESCRIPTION

**FLEXIDECK™ P-B**  
**ICC-ES #ESR-2785**  
**Class B Fire Rated System**  
**for 5/8" Plywood**

DESIGNED <b>B. CLANTON</b>	SHEET <b>1 OF 1</b>
DRAWN <b>N. BASTANI</b>	SCALE <b>N.T.S</b>
DATE <b>5/18/2017</b>	DETAIL NO. <b>P-B</b>